

# OWNERS INSTRUCTION MANUAL

VITAL-X™ 430 ELITE CROSSBOW

MODEL 5040-E





## WARNING

YOU MUST READ, UNDERSTAND AND FOLLOW ALL WARNINGS AND INSTRUCTIONS IN THIS MANUAL BEFORE USING THIS CROSSBOW! **CONTACT KILLER INSTINCT® AT 810-626-3026** 

OR EMAIL OR CONTACT@KILLERCROSSBOWS.COM WITH QUESTIONS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN SERIOUS INJURY OR DEATH!

## **WARNINGS OF GREAT IMPORTANCE** ARE FOUND ON FOLLOWING PAGES:

Introduction	2
Safety Information	3
No Alterations	4
Manual Safety	9
Crossbow Arrow Safety	10
Cocking Crossbow	11
Hand Placement	13
Loading & Shooting	14
Unloading	15

**OTHER WARNINGS AND CAUTIONS** APPEAR THROUGHOUT THE MANUAL.

#### Introduction 2 Safety Information 3 No Alterations 4 Nomenclature 5 6 **Crossbow Assembly** 9 Trigger Box & Anti-Dry Fire 9 Manual Safety **Crossbow Arrow Safety** 10 **Cocking Crossbow** 11 Proper Finger, Thumb & Hand Placement 13 14 **Loading & Shooting** Sighting in Scope 15 Unloading 15

**TABLE OF CONTENTS** 



## REGISTER ONLINE FOR LIMITED LIFETIME GUARANTEE!

Warranty

Registration

Maintenance, Care & Storage

**Trouble Shooting & Records** 

Register at:

HTTPS://WWW.KILLERCROSSBOWS.COM/REGISTER

THIS INSTRUCTION MANUAL MUST ALWAYS ACCOMPANY THIS CROSSBOW AND BE TRANSFERRED WITH IT UPON CHANGE OF OWNERSHIP, WHEN LOANED, OR PRESENTED TO ANOTHER PERSON.







16

17

18

19

## **INTRODUCTION:**

Congratulations on your new Killer Instinct® crossbow purchase! Thank you for your support. Your crossbow has been designed, manufactured, tested, and delivered to be safe when used with all the instructional information provided. Before assembly, make the first step with your new crossbow be to read and thoroughly understand all the information and instructional materials included with this product. Read and understand the Owners Instructional Manual from cover to cover. YOU MUST READ, UNDERSTAND AND FOLLOW ALL WARNINGS AND INSTRUCTIONS IN THIS MANUAL BEFORE USING THIS CROSSBOW! THIS INCLUDES ANY INFORMATION PROVIDED ON THE CROSSBOW, ARROWS, PACKAGING, HARDWARE, ACCESSORIES, OR OTHER ITEMS PROVIDED. CONTACT KILLER INSTINCT® AT 810-626-3026 OR CONTACT@KILLERCROSSBOWS.COM WITH ANY QUESTIONS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN SERIOUS INJURY OR DEATH! When used in accordance with all the instructional information provided and with proper care and maintenance, your crossbow will provide years of service. Keep and save all instructional materials provided. If crossbow transfers ownership, loaned or presented to another person, Owners Instruction Manual must be kept with crossbow and new owner/borrower must read and understand all instructions and warnings in the Owners Instruction Manual before using crossbow.

A crossbow is a deadly weapon! As such, crossbows should be treated as firearms in regards to care and safety.

The five basic rules of firearms & crossbows safety:

- Always point a firearm/crossbow in a safe direction.
- Treat every firearm/crossbow as if it were loaded and never assume a firearm/crossbow is unloaded.
- Keep your finger out of the trigger guard and off the trigger until ready to shoot.
- Keep all parts of body and clothing out of path of bow string and cables of crossbow and out of path of projectile of firearm/crossbow.
- Be sure of your target and what is beyond your target.

Crossbows by design, use a bow string and shoot projectiles at high rates of speed and should only be used by those that have completed a Hunter's Safety Course or trained by a qualified professional. Always use caution to keep all parts of body and clothing out of path of bow string and cables. High speed moving bow strings can cause serious injury if contact occurs such as finger and thumb amputation. Know your target. Projectiles that do not remain on target can cause serious injury or death. Wear safety glasses when cocking, loading and shooting any crossbow. Think Safety First and Practice Safety First. Safety Starts with You! YOU MUST READ, UNDERSTAND AND FOLLOW ALL WARNINGS AND INSTRUCTIONS IN THIS MANUAL AND ALL OTHER INSTRUCTIONAL MATERIALS PROVIDED BEFORE USING THIS CROSSBOW



CROSSBOW USE FOR EXPERIENCED USERS ONLY! CROSSBOWS SHOULD ONLY BE USED BY THOSE THAT HAVE COMPLETED A HUNTER'S SAFETY COURSE OR TRAINED BY A QUALIFIED PROFESSIONAL.





Crossbow is a deadly weapon! Always keep crossbow pointed in safe direction.

Never point at or toward person(s) or at or toward anything you do not intend to shoot.

Always be certain of intended target and what is beyond it before shooting. Never shoot at noise or movement.

Always be aware of your surroundings and ensure no other person or animal is between you and target area.

Always make certain others are well behind you before you shoot.

Never shoot straight up or in any direction that may endanger people or other objects.

Never shoot at hard surfaces or at surface of water. Arrow may bounce back or ricochet and hit someone or an unintended target.

Always keep thumb and fingers below flight rail, string, barrel and behind cables.

To prevent accidental discharge, always keep crossbow safety on 'SAFE'. Only position safety to 'FIRE' when ready to shoot.

Never store or transport crossbow in cocked or loaded position. Accidental discharge could occur.

Keep crossbow out of reach of children!

Always wear full body harness (not included) that has been certified by a Third Party Testing Facility that meets or exceeds Industry Standards when hunting from treestand or at heights.

FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN SERIOUS INJURY OR DEATH!

## **IMPORTANT SAFETY INFORMATION:**

**AWARNING** 

- Never dry fire crossbow (fire without arrow loaded). This will void warranty, damage crossbow and may cause serious injury or death.
- Never put your finger on trigger until you are ready to shoot as you could accidently fire crossbow causing serious injury or death
- Do not modify crossbow or remove or deactivate crossbow's safety features.
- Never walk, stalk, or carry crossbow with arrow loaded in crossbow. It is acceptable to carry a cocked but unloaded crossbow.
- Always use caution to keep all parts of body and clothing out of path of bow string and cables.
- Never fire crossbow if branches, tree, blind windows/walls, or obstructions may contact crossbow or crossbow limbs in its release path.
- Always keep crossbow string and cables away from sharp objects as they may cut string or cables. DO NOT
  use if string or cables are cut or show signs of wear, contact Killer Instinct® at 810-626-3026 or e-mail
  support at <a href="mailto:contact@killercrossbows.com">contact@killercrossbows.com</a> or take to an authorized Killer Instinct® dealer for inspection.
- If under age of 18 do not use without adult supervision.
- Always place broadheads in quiver when transporting or storing crossbow to prevent contact with string/cables.
- Never use crossbow while taking or under influence of drugs (even prescription drugs) or alcohol.
- Wear safety glasses when cocking, loading and shooting any crossbow.
- Always obey all safety rules and laws covering ownership and use of this crossbow in your state, hunting or shooting area. Locate and read all such rules prior to using crossbow.
- Only use crossbow for intended use of hunting and target shooting. Do not use for any other purpose!











## IMPORTANT SAFETY INFORMATION CONTINUED:

- Do not climb up or down a tree with crossbow or hoist loaded crossbow. Always unload crossbow and use hoist rope to lift up and down tree or elevated hunting platform.
- Never modify your crossbow in any way by making repairs, replacing parts, altering, adding or attaching anything to it other than Killer Instinct® accessories designed specifically for Killer Instinct® crossbows.
- When target practicing, always set up proper crossbow target and backstop in safe open area with nothing beyond target you do not intend to shoot.
- When cocking crossbow, use proper lifting techniques to avoid injury to back (lift with arms and shoulders).
- Never use this product when feeling ill, nauseous, dizzy or if you have pre-existing medical condition that could cause a problem cocking or shooting crossbow.
- Examine crossbow and arrows after every shot for worn, loose, damaged or missing parts and cracks or damage to arrows. If damage is suspected, DO NOT use crossbow and arrow(s), contact Killer Instinct® at 810-626-3026 or e-mail support at <a href="mailto:contact@killercrossbows.com">contact@killercrossbows.com</a>.
- Do not use crossbow if it is not in top working condition, contact Killer Instinct® at 810-626-3026 or e-mail support at <a href="mailto:contact@killercrossbows.com">contact@killercrossbows.com</a> for assistance.

## **NO ALTERATIONS OR ADJUSTMENTS:**



Do not modify, remove, or deactivate crossbow's safety features.

Do not modify crossbow in any way by making repairs, replacing parts, altering, adding or attaching anything to it.

#### DO NOT ALTER CROSSBOW!

This product is designed to function properly in its original condition. Alterations can make it unsafe. Do not alter, add, or substitute parts or accessories not made by Killer Instinct<sup>®</sup>.


#### DO NOT TIGHTEN OR LOOSEN LIMB BOLTS!

Do not attempt to adjust limb bolts by tightening or loosening bolts. Limb bolts are factory adjusted to specific torque specifications to optimize crossbow performance.

Do not attempt to change string, cables or limbs without proper tools and instruction. Always have qualified Killer Instinct® professional or authorized Killer Instinct® dealer perform these maintenance procedures.

NOTE: A crossbow press and qualified technician is required to change/install string, cables, limbs, cam assemblies, etc.







KILLERINSTINCTCROSSBOWS.COM




## **VITAL-X 430 ELITE NOMENCLATURE:**

- **Unpack and Check**
- Review & Confirm all items are included in Parts List. If they are not, stop and contact Killer Instinct® customer service before continuing or using this product.

#### Included in the Box

- (1) Stock Assembly (Stock, Buttstock, Trigger Box, Arrow Retainer, Grip, Forearm Grip)
- (1) Front End Assembly (Riser, Limbs, Cams, String, Cables, String Suppressors, Limb Dampeners)
- (1) Scope, (CR2032 Battery), Scope Rings, Scope Caps
- (1) Quiver w/Offset Quiver Bracket
- (3) 20" Hypr™ Bolts w/Half Moon Nocks
- (1) Accessory Pack including Cable Slide, Rail Lube, Foot Stirrup, Rope Cocker, Quiver Bracket, Riser Gasket, and Safety Manual





**KEEP THUMB / FINGERS** ON FOREARM GRIP AND BELOW FLIGHT RAIL AND CABLES



KILLERINSTINCTCROSSBOWS.COM

Note: Actual model may differ than one shown. Not shown: Quiver System







## DO NOT MODIFY CROSSBOW! QUESTIONS CALL 810-626-3026

Do not modify, remove, or deactivate crossbow's safety features.

Do not modify crossbow in any way by making repairs, replacing parts, altering, adding or attaching anything to it.

**AWARNING** 

Killer Instinct® and Killer Instinct® authorized dealers are the only repair facilities authorized to open or disassemble crossbow or make repairs/replacements of strings, serving, cables, limbs, trigger boxes, barrels, etc. Unauthorized repairs may void warranty. If repairs are needed, contact Customer Service at 810-626-3026 or e-mail support at <a href="mailto:contact@killercrossbows.com">contact@killercrossbows.com</a> for assistance.

#### **RAIL LUBE**

**PRIOR TO ASSEMBLY** apply Rail Lube to string, cables, both sides of cable slide, and flight rail. RAIL LUBE MUST BE APPLIED TO STRING, CABLES AND FLIGHT RAIL ON REGULAR BASIS TO PREVENT WEAR. Apply as often as needed or when rail lube appears to have worn off flight rail, string or cables.

With top of riser facing up, Cable

#### ATTACHING FRONT END TO BARREL AND INSTALLING FOOT STIRRUP

#1 Attach the Cable Slide to the Cables to the right of the cross in the Cables.

The cables fit into the grooves on the bottom of the Cable Slide. The deeper groove in the Cable Slide is intended for the top crossing cable.

Make sure the curved side of the Cable Slide is facing up when the top of the Riser is facing up.

Insert the black plastic gasket onto the Riser as shown.

Slide the Cable Slide into the stock with the string on top of the barrel.

#2 Holding Cable Slide in place (Riser and Stock facing up), insert the Cable Slide and Cables into the Stock so the groove on the Cable Slide aligns with the groove in the stock. Continue inserting the Cable Slide and cables into the Stock while keeping the String on top of the Barrel.




CAREFULLY INSERT CABLES AND CABLE SLIDE INTO BARREL SLOT TO PREVENT CABLE PINCHING OR CABLE CONTACT WITH EDGES OF BARREL! CABLE SLIDE MUST BE INSTALLED BEFORE ATTACHING FRONT END!



## **CROSSBOW ASSEMBLY CONTINUED:**

#3 Push the Riser completely against the Barrel, making sure the Riser lines up with the Barrel and there is no gap.



Note: make sure the middle Allen Set Screw (2) does not interfere with the Riser Bolt at this point.




Securely tighten Riser Bolt (1) so the Riser contacts the Barrel and there is no gap between the Riser and the Barrel.

Tighten the middle Allen Set Screw (2) to lock the Riser Bolt in place.


Place the Foot Stirrup into the #5 outer holes of the Riser. Align the 2 flats of the Foot Stirrup so the holes in the Riser match.

> Tighten the Foot Stirrup into place by using the (2) included Allen Set Screws.

> Double check that all (3) Allen Set Screws are securely tightened.












## **QUIVER AND SCOPE:**

#### QUIVER

Attach the guiver bracket to the bottom of the riser using (2) included 1/8 Hex screws.

Slide the quiver onto the quiver bracket.

Once assembled, close the locking lever to secure the quiver.







#### OFFSET QUIVER BRACKET

Attach the quiver bracket to the picatinny rail using (2) included 5/32 Hex bolts and nuts.

Slide the quiver onto the quiver bracket.

Once assembled, close the locking lever to secure quiver.





#### **LUMIX SCOPE**

Loosen the (4) Hex screws on top of the scope rings. Remove the scope ring attachment nuts and clamps as shown. Align the scope ring clamp screws in (2) grooves on the picatinny rail. Attach the scope to the picatinny rail on top of the trigger box.

Reinstall the scope ring clamps (Thick side up) and secure the scope to the picatinny rail using the scope ring attachment nuts as shown.










Thick side up

## TRIGGER BOX AND ANTI DRY-FIRE:

## **AWARNING**

Never lift Anti-Dry Fire mechanism and move safety to 'FIRE' when crossbow arrow is not loaded. This deactivates Anti-Dry Fire allowing crossbow to be dry fired.

Never Dry Fire crossbow. This will void warranty and may cause serious injury or death. Always keep crossbow safety in 'SAFE' position when cocked until ready to shoot.



## ANTI-DRY FIRE RELEASE MECHANISM: USE ONLY WHEN CROSSBOW IS UNCOCKED!

When crossbow is uncocked, the manual safety is designed to be in the 'FIRE' position as shown above. The auto engaging manual safety will travel from the 'FIRE' position to 'SAFE' position when the crossbow is properly cocked. The anti-dry fire mechanism will not allow the manual safety to move into the 'FIRE' position until an arrow is properly loaded. (see Loading and Shooting – Page 14).

## **OPERATION OF TRIGGER BOX MANUAL SAFETY:**



Even though crossbow is equipped with auto engaging safety, always check to assure safety is in 'SAFE' position when crossbow is in cocked position.

Always keep crossbow safety in 'SAFE' position until ready to shoot.

#### INSTRUCTION

## SAFETY IN 'SAFE' (S) POSITION

Safety is in 'SAFE' position when manual safety is in back position (furthest from string).



Always keep crossbow safety in 'SAFE' position until ready to shoot.


## SAFETY IN 'FIRE' (F) POSITION

Safety is in 'FIRE' position when safety is in forward position (closest to string).



Crossbow will fire when trigger is pulled.

#### **IMAGE**









## **CROSSBOW ARROW SAFETY:**



Only use arrow(s) with half moon nocks.

Only use finished arrow(s) (arrow and point) weighing at least 390 grains and minimum length 20 inches. Under weight arrows can damage crossbow. Failure to follow these instructions can result in serious injury or death!

#### **CROSSBOW ARROW SELECTION:**

Always use a finished arrow(s) (arrow and point) weighing at least 390 grains and minimum length of 20 in. Always use arrow(s) with half moon nocks.

Always use field point or broadhead installed on arrow. NEVER SHOOT CROSSBOW ARROW WITHOUT FIELD POINT OR BROADHEAD.



Always inspect arrow(s) before every shot for damage including but not limited to bends, cracks, nicks, cuts, fractures, damaged nock, missing insert or point. DO NOT SHOOT A DAMAGED ARROW OR IF DAMAGE IS SUSPECTED. Failure to follow these instructions can result in serious injury or death!

#### **INSPECTING CROSSBOW ARROWS:**

Always inspect arrow prior to every shot. Damage can occur from impacts with hard objects, other arrows or after being shot into a game animal. A damaged arrow can break upon shot resulting in injury to you, bystanders and damage crossbow.

- 1. Slowly run your fingers along entire length of arrow and nock, feeling and looking for bends, cracks, nicks, cuts, fractures, splits, dents or other marks that could indicate damage. If damaged or suspect damage do not shoot arrow.
- 2. Grab arrow above point and below nock, then flex arrow (bending away from you and others) with 0.5 to 1 inch deflection and listen for cracking noises. Repeat 5 or 6 times rotating arrow between each flex. If you feel or hear cracking, arrow has been damaged. Do not shoot arrow.
- 3. While holding both ends of arrow, twist shaft in both directions. If arrow relaxes or twists easily, arrow has been damaged. Do not shoot arrow.
- 4. Always check all arrow components prior to shooting. Tighten loose components. Loose components can cause unbalanced flight and may partial dry fire crossbow.



Never shoot crossbow arrow(s) if you observe or suspect damage! Discard damaged arrow.

#### **VISIT: WWW.SAFEARROW.INFO**

For more information on crossbow arrow safety, visit: <a href="www.safearrow.info">www.safearrow.info</a> prior to using your crossbow.







## **COCKING CROSSBOW:**

## **WARNING**

Do not cock crossbow by hand as possible back, shoulder or finger injuries may occur. Always use rope cocking device or Crank Cocker (sold separately) to cock crossbow. Never cock or use crossbow when feeling ill, nauseous, dizzy or if you have prior

medical condition that could cause a problem cocking or shooting crossbow. When cocking crossbow use proper lifting techniques to avoid injury to back (lift with arms and shoulders).

Do not de-cock crossbow with a cocking device or by any other means. (See UNLOADING CROSSBOW section on page 15 to de-cock crossbow)

#### **USING ROPE COCKING DEVICE:**

IMPORTANT NOTE: ALWAYS USE COCKING DEVICE OR CRANK COCKER (SOLD SEPARATELY). THESE DEVICES EVENLY PULL STRING TO COCKED POSITION RESULTING IN IMPROVED ACCURACY AND TIGHTER GROUPS.

#1 When crossbow is unloaded, make sure safety is in 'FIRE' (F) position before cocking crossbow. If not in FIRE, string latch will not engage or hold the string.

Make sure flight rail, string and cables are lubed and safety is in the 'FIRE' position. Place crossbow stirrup on the ground (buttstock up). Insert foot through stirrup so foot extends through stirrup and stirrup rests in middle of foot.

#2 Place crossbow stirrup on the ground (buttstock up). Insert foot through stirrup so foot extends through stirrup and stirrup rests in middle of foot.





#3 Holding the Sled Hook in one hand, grab the center of the Rope Cocker cord in the center of the Sled Hook. Pull the cord until the handles are against the Sled Hook and place the center of the cord in the rope cocker groove.

Pull the Sled Hook over the scope and attach it to the string as shown.











## **COCKING CROSSBOW (CONTINUED):**

#4 Keep foot through the Foot Stirrup flat on the ground, grab Rope Cocker handles and pull up and back towards your hips (using legs, shoulders and arms) until string fully engages the string catch.

You will hear a defined "click" when the string catch is properly engaged. The Crossbow is now cocked.



ALWAYS MAKE SURE STRING FULLY ENGAGES STRING CATCH BEFORE RELEASING TENSION ON ROPE COCKER.



KEEP HANDS AND FINGERS OUT OF STRING PATH WHEN REMOVING SLED HOOK ROPE COCKER AFTER COCKING CROSSBOW.

#5 Completely remove the Sled Rope Cocker from the crossbow.

Keep fingers out of the string path when removing Rope Cocker.

Push the Sled down and lift up and away from the string.







#6 Even though safety automatically engages when cocked, make certain crossbow is in 'SAFE' position (back position furthest from string).









## PROPER FINGER, THUMB, AND HAND PLACEMENT:



Always keep thumb and fingers below string, flight rail, barrel and behind / below cables. Failure to do so may result in serious injury to hand, including possible thumb or finger amputation.



## **INSTRUCTION**

### **IMAGE**

## **CORRECT!**

Keep trigger hand on grip behind trigger. Always keep other hand securely gripping Forearm Grip with fingers and thumb below strings path, flight rail, barrel and behind / below cables.



## **INCORRECT!**



THUMB OR FINGERS ABOVE BARREL AND IN STRINGS PATH! DO NOT SHOOT!

## **INCORRECT!**



THUMB, FINGERS OR HAND OFF OR BEHIND OR IN FRONT OF FOREARM GRIP AND ABOVE BARREL! DO NOT SHOOT!











## **LOADING AND SHOOTING:**



Even though crossbow is equipped with anti-dry-fire device, do not pull trigger without arrow properly loaded.

Always keep crossbow safety in 'SAFE' position until ready to shoot.

## STEP INSTRUCTION

#1 Keeping hand in 'Safe Loading Area' place a Killer Instinct® recommended crossbow arrow into the flight groove on top of the barrel (odd color vane down) into flight groove ensuring the groove of the nock is parallel to the string. It not, orientate the crossbow arrow so the nock groove is parallel to the string.

#2 Keeping hand in 'Safe Loading Area', slide arrow back under arrow retainer until the groove of the nock rests solidly against string. Arrow must be against string before firing!




Always keep crossbow aimed in safe direction during loading arrow and when loaded.

Before shooting always make sure arrow nock rests firmly against string to prevent dry firing crossbow, which could cause bodily injury and/or void warranty.

#3 While aiming in a safe direction, push safety selector to the fire position. Keep hand and fingers below finger/thumb guard as shown. Aim, push safety to the fire position and slowly squeeze trigger to shoot the crossbow.

#### **IMAGE**







# **AWARNING**

Always keep crossbow safety in 'SAFE' position until ready to shoot.

Always keep thumb, fingers and any other body appendages below and away from flight rail, string, barrel, cables and cams.

Never shoot without arrow or arrow firmly next to string.

Always keep crossbow aimed in safe direction during loading and when loaded.

Always be certain of intended target and what is beyond it before shooting.

Never shoot straight up or in any direction that may endanger people or other objects. Never shoot at hard surfaces or at surface of water. Arrow may be damaged, bounce back or ricochet and hit someone or an unintended target.

FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN SERIOUS INJURY OR DEATH!


## **SIGHTING IN SCOPE:**

#1 Shoot at 10 yards using top scope reticle to confirm you are close to bullseye. Make windage/ elevation adjustments to get closer to bullseye. *Approximately* 10 clicks = 1" @ 20 yards.

Increase distance to 20 yards and fine tune sope. Continue shooting at additional yardages using lower scope reticles. Lower reticles are for greater distances. **NOTE:** Each reticle line represents approximately 10 yard increments (using 400 grain total arrow weight). This may vary with aftermarket arrows and different weight field tips / broadheads.

**SHOOTING TIP:** For increased accuracy and tighter groups, follow through with your shot by watching arrow hit target through scope.

SHOOT AT 10 YARDS AIMING WITH THE CENTER OF THE CROSSHAIR



ADJUST SCOPE RETICLE TOWARDS POINT OF AIM (BULLSEYE) UNTIL ZEROED IN

TOP TURRET: ELEVATION (UP & DOWN)

(UP): COUNTER-CLOCKWISE (DOWN): CLOCKWISE

( LEFT & RIGHT )
(LEFT): CLOCKWISE
(RIGHT): COUNTER-CLOCKWISE

RIGHT TURRET: WINDAGE






MOVE TO 20 YARDS AND RE-ZERO CENTER SCOPE RETICLE

EXAMPLE: SHOT HITS 1" LEFT, 2" HIGH

- ADJUST WINDAGE (SIDE TURRET) COUNTER-CLOCKWISE 10 CLICKS.
- ADJUST ELEVATION (TOP TURRET) CLOCKWISE 20 CLICKS.



## **UNLOADING & DECOCKING CROSSBOW:**



Always use Killer Instinct® recommended arrow to unload crossbow.

Do not de-cock crossbow by hand, cocking rope or crank or by any other means other than shooting an arrow or appropriate discharge arrow.

#### **UNLOADING CROSSBOW:**

Recommended and safest way to unload crossbow is to fire arrow into suitable target or rock-free ground. If firing into ground, make sure ground is not frozen or hard and shoot at point approximately 4 to 5 feet in front of you at 45 degree angle. Firing at greater distances may result in lost arrow in dirt or ricochet.

#### TIME ALLOWED TO KEEP CROSSBOW COCKED:

Crossbow can remain cocked 12 hours. Do not leave crossbow cocked overnight or when transporting.











## **MAINTENANCE, CARE AND STORAGE:**



Always examine crossbow and crossbow arrows after every shot for worn, loose, damaged or missing parts and cracks or damage to arrows. DO NOT use worn or damaged crossbow or crossbow arrow(s). Always store crossbow uncocked and out of reach of children.

SCHEDULE	MAINTENANCE
PRIOR TO EVERY SHOT	Thoroughly check crossbow and crossbow arrow for worn, loose, damaged or missing parts every time you use crossbow. Do not use worn or damaged crossbow or crossbow arrow(s).
PRIOR TO EVERY SHOT	Check and confirm arrow retainer is in good working order as it is designed to apply consistent downward pressure on arrow.
PRIOR TO FIRST SHOT  EVERY 5 – 10 SHOTS	Lube flight rail with Killer Instinct® rail lube to increase arrow speed and reduce friction to extend life of string, serving and cables.  Re-apply rail lube on flight rail, string and cables as often as needed or after every 5 to 10 shots.
AFTER INITIAL 20 SHOTS ANNUALLY OR AS NEEDED	Check screws/bolts for tightness on crossbow scope base, scope rings, riser bolts, quiver base and string suppressors.
ANNUALLY OR AS NEEDED	Annually or as needed apply rail lube to cable slide.
IMMEDIATE IF WEAR IS DETECTED EVERY 2 YEARS	Immediately replace worn, cut or frayed string, serving and cables prior to shooting. Keep string, serving and cables lubed with Killer Instinct® rail lube. Killer Instinct® recommends replacing string, serving and cables every three years in normal hunting/shooting conditions or sooner if signs of wear exist.
EVERY 3 YEARS	To maintain your Limited Lifetime Warranty, you must have service inspections every 3 years.
IMPORTANT	Killer Instinct® and Killer Instinct® authorized dealers are the only repair facilities authorized to open or disassemble crossbow or make repairs/replacements of strings, serving, cables, limbs, trigger boxes, barrels, etc.  Unauthorized repairs may void warranty. If repairs are needed, contact Customer Service at 810-626-3026 or e-mail support at <a href="mailto:contact@killercrossbows.com">contact@killercrossbows.com</a> for assistance.

#### **CARE**

Keep flight rail, cams, cables, string, trigger box and trigger clean and free of debris, mud, dirt, etc.

After exposing crossbow to damp or wet conditions, completely dry off crossbow before storing.


Do not expose crossbow in excessive heat such as leaving in an automobile on a hot day.

### **STORAGE**

Store crossbow in uncocked position and out of reach of children.

Store indoors in a cool dry location away from excessive heat and moisture.









TR	TROUBLE SHOOTING:			
	PROBLEM	SOLUTION		
#1	Burning smell after shot	Re-apply Killer Instinct® rail lube to flight rail, string, cables and/or cable slide. Keep fingers out of cable slot on barrel.		
#2	String, serving and/or cables are fuzzy	Apply thin coating of Killer Instinct® rail lube on string, serving and cables and rub lube into string and cables rubbing between your fingers.		
#3	String and/or cable serving is coming apart or separating	<b>Do not use crossbow.</b> Replace string and cable or reserve string and cable. Take your crossbow to an authorized Killer Instinct® retail dealer or contact Customer Service at 810-626-3026 or at <a href="mailto:contact@killercrossbows.com">contact@killercrossbows.com</a> for assistance.		
#4	String and/or cables are cut or fraying	<b>Do not use crossbow.</b> Replace string and/or cables. Take your crossbow to an authorized Killer Instinct® retail dealer or contact Customer Service at 810-626-3026 or at <a href="mailto:contact@killercrossbows.com">contact@killercrossbows.com</a> for assistance.		
#5	Unable to cock crossbow	Make sure the safety is in the "Fire" position prior to cocking the crossbow. If the safety is in the "Safe" position, follow the "Anti-Dry Fire Release Mechanism" on page 9. If questions, contact Customer Service at 810-626-3026 or at contact@killercrossbows.com for assistance.		
#5	Additional Problems	Take your crossbow to an authorized Killer Instinct® retail dealer, contact Customer Service at 810-626-3026 or at <a href="mailto:contact@killercrossbows.com">contact@killercrossbows.com</a> for assistance.  Visit www.huntkillerinstinct.com for additional information.		

## **CROSSBOW OWNER'S RECORD**

FILL IN THE FOLLOWING CROSSBOW RECORDS FOR QUICK REFERENCE.

CROSSBOW SERIAL NUMBER:	
CROSSBOW MODEL NUMBER:	
PURCHASED FROM:	
PURCHASED DATE:	

#### **IMPORTANT:**

REGISTER YOUR CROSSBOW AND SAVE YOUR SALES RECEIPT AND SERIAL NUMBER. THIS PROOF WILL BE REQUIRED FOR YOUR FREE INSPECTION AND IS REQUIRED SHOULD YOUR CROSSBOW EVER NEED WARRANTY SERVICE.

ATTACH SALES RECEIPT TO OWNERS MANUAL FOR SAFEKEEPING.	
NOTES:	





## KILLER INSTINCT® LIMITED LIFETIME WARRANTY\*.

#### LIMITED LIFETIME WARRANTY

Your Killer Instinct® crossbow is warranted against any manufacturer defects for the life of the crossbow to the **original, registered owner**. This includes all crossbow parts except standard use wearable components (string, serving, cables, cable slide), accessories (rubber parts, arrows/bolts, rope cocker, scope, etc.) and cosmetic appearance (scratches, marks, chips) caused by normal use and wear. **Labor costs associated with all repairs and regular maintenance are not covered under warranty and is the responsibility of the consumer**. Contact your authorized Killer Instinct® retailer or customer service at 810-626-3026 or e-mail contact@killercrossbows.com for warranty claims. Any and all warranties, written or implied, are void with any alterations to the crossbow.

**REGISTRATION TO ACTIVATE FREE LIFETIME SERVICE INSPECTION AND LIMITED LIFETIME WARRANTY**Register within 30 days of your purchase online at www.Killerinstinctcrossbows.com.

#### **SERVICE INSPECTION REQUIRED**

Failure to properly maintain your crossbow including regular string/cable maintenance, proper lubrication, etc. will void warranty. Product inspections are required every 3 years by Killer Instinct Dealers from the date of purchase to maintain your limited lifetime warranty. Any costs associated with inspection, repair costs or freight costs are the responsibility of the crossbow owner. Please visit www.killerinstinctcrossbows.com to download your required service form. The completed service form must be received by Killer Instinct to continue limited lifetime warranty.

#### SERVICING YOUR KILLER INSTINCT® CROSSBOW:

If you need repairs, have warranty issues or need your 3 year service inspection, take your registered crossbow with copy of original receipt to an authorized Killer Instinct® retail dealer or contact Customer Service at 810-626-3026 or e-mail support at contact@killercrossbows.com for assistance.

The owner is responsible for all shipping costs for crossbows returned to Killer Instinct® for inspection.

All labor costs associated with maintenance, repairs/replacements resulting from general service or the free lifetime service inspection are the responsibility of the owner.

#### **WARRANTY IS VOID IF**

- The Killer Instinct® crossbow is damaged from Accidents, abuse, mishandling, dry-firing, alterations or modifications to the original product.
- The Killer Instinct® crossbow is not registered within 30 days.
- The Killer Instinct® crossbow is not the original owner
- The Killer Instinct® crossbow is older than 3 year from date of purchase and has not received Free Lifetime Service Inspection.

#### LIMITATION OF LIABILITY

USE ONLY AS INTENDED. MANUFACTURER ASSUMES NO RESPONSIBILITY FOR INJURY, DAMAGE OR LOSS ARRISING FROM THE USE OF THIS PRODUCT HOWSOEVER CAUSED.

#### **PLEASE NOTE:**

Killer Instinct® reserves the right to make substitutions on warranty coverage for any reason, including but not limited to available parts.

\*Limited Lifetime Warranty to the Original Owner.

\*\*Free inspection does not cover labor costs, freight costs, or costs associated with replacement/repair of parts of excluded from Limited Lifetime Warranty.

Killer Instinct® Crossbows Phone: 810-626-3026

Email: contact@killercrossbows.com Website: www.Killerinstinctcrossbows.com

Receiving Address: 393 List St., Suite B Frankenmuth, MI 48734



Distributed by: KILLER INSTINCT INC. 393 List St. Ste B Frankenmuth, MI 48734

KILLER INSTINCT® is a registered trademark of KILLER INSTINCT INC. ALL RIGHTS RESERVED









# REGISTER ONLINE FOR LIMITED LIFETIME GUARANTEE!

Register at:

https://www.killerinstinctcrossbows.com/register

## Easy Quick-Step Directions:

- 1. https://www.Killerinstinctcrossbows.com/register
- 2. Upload copy of receipt or proof of purchase
- 3. Enter in your contact information
- 4. Enter retailer purchased from, bow model and serial number
- 5. Click Submit! Now you are covered!

Questions? We can help! Call us at: 810-626-3026 or

Email: contact@killercrossbows.com











REGISTER YOUR CROSSBOW







